





12-week trial (February – May 2023)


Aim: "Trial transporting chemotherapy medicines from Wansbeck General Hospital to Alnwick and Berwick Infirmaries."

Northumbria Healthcare



HOSPITAL SITES

- 1 HEXHAM GENERAL HOSPITAL Corbidge Road, Hexham, NE46 1QJ
- NORTH TYNESIDE GENERAL HOSPITAL
 Rake Lane, North Shields, NE29 8NH
- WANSBECK GENERAL HOSPITAL
 Woodhorn Lane, Ashington, NE63 9JJ
- THE NORTHUMBRIA HOSPITAL
 Northumbria Way, Cramlington, NE23 6NZ
- 5 ALNWICK INFIRMARY South Road, Alnwick, NE66 2NS
- 6 BERWICK INFIRMARY
 Infirmary Square, Berwick-upon-Tweed, TD15 1LT
- 7 BLYTH COMMUNITY HOSPITAL Thoroton Street, Blyth, NE24 1DX
- B HALTWHISTLE WAR MEMORIAL HOSPITAL Westgate, Haltwhistle, NE49 9AJ
- MORPETH NHS CENTRE
 The Mount, Morpeth, NE61 1JY
- 10 ROTHBURY COMMUNITY HOSPITAL Whitton Bank Road, Rothbury, NE65 7RW



Drone specification

Skyports Swoop Kookaburra Mk III hybrid drone

Maximum take-off weight	17kg
Maximum payload	3kg
Power	Fully electric powered - Vertical take-off and landing (VTOL)
Maximum speed	78mph (68knots)
Maximum endurance	68 minutes (at maximum take-off weight)
Wind limitation	30mph (27knots) from any direction
Operating temperature limitation	0°C / +45°C

Northumbria Healthcare

Journey time:

Ashington to Alnwick (21 miles)

Ideal road journey = 31 minutes

Drone flight = 38 minutes*

(*includes road journey to/from take-off/landing sites)

Northumbria Healthcare



Journey time:

Ashington to Berwick (45 miles)


Ideal road journey = 71 minutes

Drone flight = 108 minutes*


(*includes road journey to/from take-off/landing site – and stopover at Alnwick)

Northumbria Healthcare





Northumbria Healthcare NHS Foundation Trust



Northumbria Healthcare
NHS Foundation Trust



3kg payload limitations

Northumbria Healthcare

NHS Foundation Trust

250ml bag

50ml syringe

ICECATCH cool brick







Phase 1 learning

- Cold chain difficult to maintain throughout whole journey. Deviations occurring at start/end of journey.
- Validation flights 10 empty bag, 10 full bag (mock products) both temperature conditions:
 - Fridge temperature 14/20
 - Room temperature 4/20
- In-flight temperatures during validation flights remained in range.
 Northumbria Healthcare

Phase 1 summary

 Chain of custody and Vibration not assessed during Phase 1.

 Temperature concerns preventing further validation at this stage.

■ Take forward into Phase 2.

Northumbria Healthcare

Phase 2 – What next?

Bigger drone with bigger payload.

(Previous Apian project – less reliable for multiple journeys)

More thermally efficient bag, dependent on drone capacity.





Phase 2 - next steps for Northumbria

- Engagement with MHRA GDP Inspector: long-term suitability of drone delivery considering - GDP guidelines.
- Room temperature oral products. Build up to transporting PPUmanufactured products in future phases.
- Northumbria envisages drone delivery would not replace current delivery methods, but supplement what is already in place.

Northumbria Healthcare



